


P I X S Y S

elettronica



CONTROLLER

ATR420

User Manual

Contents list

Introduction	3
1. Ordering code.....	3
2. Sizes and installation	4
3. Electrical wirings	5
4. Displays and keys.....	8
4.1 Displays	8
4.2 Meaning of leds	9
4.3 Keys	10
5. Configuration and programming	11
5.1 Entering or modifying a cycle.....	11
6. Cycle start and special functions	14
6.1 Cycle start.....	14
6.2 Function SIMPLE CONTROLLER.....	15
6.3 Auto-tuning.....	15
7. Configuration	16
7.1 Change of numeric value	16
7.2 Change of configuration parameters	16
7.3 Memory Card	18
8. Configuration parameters	19
9. Alarms operating	25
10. Software functions	27
10.1 Recovery of interrupted cycle.....	27
10.2 Waiting.....	27
11. Protocol Modbus RTU	28
11.1 Main features.....	28
11.2 Addresses of words ATR420	28
12. Error messages	30
13. Technical data	31
13.1 Main features.....	31
13.2 Hardware data.....	32
13.3 Main software data.....	33
Configuration table	34

+

Introduction

The controller ATR420 integrates control and regulation functions for process automation. It is provided with RS485 and MODBUS protocol and it maintains the key-features of all Pixsys instruments such as free configurable input and a wide range of parameters to make it easily adaptable and highly flexible.


To simplify the configuration, a special Memory Card has been conceived to copy all parameters and eventually store them for historical archive.

Sealing of cover according to IP54. Frontal extraction of electronics for easy maintenance.

1. Ordering code

ATR420-	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Input	1			1 Input TC-RTD-signals V, mA
Output		1		2 relay outputs + 1 SSR output
Power supply			AD	24/12V AC ±15% 50/60Hz
			BC	230/115V AC ±15% 50/60Hz

2. Sizes and installation




3. Electrical wirings






Although this controller has been conceived to resist the worst noises in an industrial environment, please notice the following safety guidelines:

- Separate control wires from power wires
- Avoid mounting close to remote control switching systems, electromagnetic relays, powerful engines
- Avoid proximity of power systems, especially those with phase control




3.1 Wiring plan



Power supply

 <p>SUPPLY</p> <p>1 2</p>	<ul style="list-style-type: none"> 24/12V AC $\pm 15\%$ 50/60Hz (selection by internal jumper) 230/115V AC $\pm 15\%$ 50/60Hz (selection by internal jumper)
 <p>POWER SUPPLY 24V POWER SUPPLY 12V</p>	<ul style="list-style-type: none"> Version ATR420-XXAD Select JP4 and JP5 for 12V AC Select JP3 for 24V AC
 <p>POWER SUPPLY 230Vac POWER SUPPLY 115Vac</p>	<ul style="list-style-type: none"> Version ATR420-XXBC Select JP4 and JP5 for 115V AC Select JP3 for 230V AC

Analogical input


 <p>11 12</p>	<p>1. Thermocouples K, S, R, J</p> <ul style="list-style-type: none"> Respect polarities For eventual extensions, use compensating cable and terminals suitable for the used thermocouple
 <p>11 WHITE 12 RED 13 RED Pt100</p>	<p>2. For PT100, NI100</p> <ul style="list-style-type: none"> For a three-wire wiring use cables with the same diameter 
 <p>11 + 0..10V 4..20mA 12 -</p>	<p>3. Signals V, mA</p> <ul style="list-style-type: none"> Respect polarities

Digital input




- Digital input, configurable from parameter 17 as N.O. and N.C.

Serial input




- RS485 Modbus


Relay outputs / SSR output



- Contacts capacity 8A/250V~ resistive
- Control relay setting 0 on parameter 5 (**P-05**).
 - Relay alarm 1 with SSR control setting 1 on parameter 5 (**P-05**).



- Contacts capacity 8A/250V~ resistive
- Relay alarm 2.



- Capacity 12V/30mA
- Control output for SSR
 - Alarm 1 with control OUT1

4. Displays and keys



4.1 Displays

1



It usually visualizes the process value. During configuration it will visualize the number of entering parameter

2



This display can visualize setpoint, output percentage, elapsed time for timer, running step. During configuration it will visualize the value of entering parameter.

4.2 Meaning of leds

3		ON when display 1 or display 2 visualize setpoint value
4		ON when display 1 or display 2 visualize time value
5		ON when the unit is functioning as simple controller , not as programmer
6		ON when the controller is answering a serial polling
7		ON when control output is active
8		ON when OUT2 is active
9		ON when alarm 1 or auxiliary 1 is active
10		ON when alarm 2 or auxiliary 2 is active

4.3 Keys

11		<ul style="list-style-type: none"> • Scroll through the parameters during the configuration. • Scroll the cycles to program or to start • Modify time and setpoint values during cycle programming • Modify setpoint when the function HOLD is active • Fast advancement on cycle
12		<ul style="list-style-type: none"> • Scroll through the parameters during the configuration. • Scroll the cycles to program or to start • Modify time and setpoint values during cycle programming • Modify setpoint when the function HOLD is active • Fast go-back
13		<ul style="list-style-type: none"> • Visualize duration of last executed cycle with controller in STOP-mode • Move to next flashing digit during parameters configuration • Scroll and visualize timer, step, output % and setpoint during cycle execution
14		<ul style="list-style-type: none"> • Enter cycles selection and configuration mode when the controller is in STOP-mode • Press it for ab. Durante un ciclo, se sec. During cycle execution to start or stop the function HOLD.
15		<ul style="list-style-type: none"> • START a new cycle or STOP the running cycle • ESCAPE –key if programming parameters or cycles.
15		<ul style="list-style-type: none"> • Confirm the selected value or function.

5. Configuration and programming

1. Configuration means programming of basic parameters (type of input/output, alarms operating....)
2. Cycle programming means entering values of time and setpoint/temperature for each step/segment of the cycle

5.1 Entering or modifying a cycle

The controller must be in STOP-mode.

	Press	Display	Do
1		Display 2 visualizes 	
2		Visualize (for cycle no. 1), (for cycle no. 2) and so on	Press one of the arrow keys until the chosen program is visualized
3		Display 2 visualizes . Display 1 visualizes the waiting time before START and led TIME is ON. If this function is not required , go to point 5	Anytime press to quit the programming mode , storing the modified data.
4		Increase / decrease the value on display 1.	Enter the value for waiting time before cycle start. Setting value 0, display 1 visualizes

5		Display 2 visualizes St. 0 . Display 1 visualizes the starting setpoint and led SPV is ON. Otherwise go to point 7	
6		Increase/ decrease value on display 1.	Enter the value of starting setpoint, which means the reference value for the controller to rate the gradient of first step (this is usually the ambient 25°C).
7		Display 2 visualizes the step which is being modified. Display 1 visualizes the duration of the step and the led TIME is On.	
8		Increase/decrease the value on display 1.	Enter the duration of step (hours : minutes) Choose End for end of the cycle and go to point 15.
9		Display 2 visualizes the step which is being modified . Display 1 visualizes setpoint and led SPV is ON	
10		Increase/decrease the value on display	Enter setpoint value

11		If auxiliary output 1 is not timed, go to point 13 Display 1 visualizes or and led A1 is ON	
12	 	Press to visualize , press to visualize .	Set the state of auxiliary output for each step: for active output or for desabled output
13		If auxiliary output 2 is not timed, go to point Display 1 visualizes or and led A2 is ON	
14	 	Press to visualize or press to visualize .	Set the state of auxiliary output for each step: for active output or for desabled output Go back to point 7
15		If auxiliary outputs 1 or 2 are not timed, the controller returns to STOP-mode and stores the cycle. Display 2 visualizes .	If outputs are programmed as auxiliaries, repeat points 12 and 14 for the state of outputs at cycle end (after STOP)

6. Cycle start and special functions

6.1 Cycle start

The controller must be in STOP-mode.

	Press	Display	Do
1		Display 2 visualizes cycle selection	
2		(for cycle no.1), (for cycle no.2) ...	Scroll the available cycles, until the chosen one is visualized on display
3	or 	Cycle starts and internal buzzer beeps. Display 1 visualize process value, display 2 visualizes setpoint value	

⚠ Function FAST ADVANCEMENT

With cycle in progress, press or to scroll the cycle onwards or backwards (each beep of the buzzer means one minute)

⚠ Function HOLD (with cycle in progress)

Press for about 1 sec. to start the function HOLD. This means that the controller stops the cycle in progress and holds the temperature until the function is stopped. Setpoint value can also

be changed by pressing . To stop the function and restart the cycle , press for about 1 sec.

⚠ To stop the cycle before it is completed and set the controller to STOP-mode , press .

6.2 Function “SIMPLE CONTROLLER”

Instead of standard operation as a programmer, the ATR420 can also function as a controller referring to the given setpoint.
The controller must be in STOP-mode to activate the function.

	Press	Display	Do
1		Display 2 visualizes cycles selection	
2		Scroll the available cycles until E-STOP is visualized. Led TRM is ON.	
3		Display 2 visualizes setpoint value . Led TRM starts flashing. Control output is activated .	
4		Increase or decrease the setpoint value on display 2.	Change setpoint if required. To quit the function, press .

6.3 Auto-tuning

Auto-tuning function can be started if the function SIMPLE CONTROLLER is running. **Process value must be at least 35% lower than setpoint value** .

	Press	Display	Do
1		TUNE flashing on display 2.	

3		tune is visualized The controller starts the auto-tuning function	Wait until setpoint value is visualized again . To quit the function before it is completed, press
---	--	---	--

7.Configuration

7.1 Change of numeric value

1. If all digits are flashing, press to change the parameter value.
2. If all digits are visualized and only one is flashing, press to change it and press to move to the next digit.

7.2 Change of configuration parameters

To change the configuration parameters (see chap. 8) , the controller must be in STOP-mode.

Press	Display	Do
1 	Display 2 visualizes cycles selection	
2 		Scroll the cycles until conf is visualized
3 	Display 1 visualizes 0000 and the 1 st digit flashes. Display 2 visualizes PASS .	

Press	Display	Do
4		Modify the 1 st flashing digit Enter password (see 7.1 , 7.2)
5		Display 1 visualizes P- <u> </u> , display 2 visualizes parameter value
6		Increase or decrease number of parameter
7		Display 2 visualizes teh flashing value.
8		Increase or decrease the value
9		Parameter value stops flashing. To change another parameter go back to point 6.
10		Press the key when configuration or change of parameter have been completed. The controller is set to STOP-mode.

7.3 Memory Card

Parameters and cycle values can be copied and stored on another controller by means of the Memory Card. Before you insert the Card, **the controller must be switched-off**. Please **check also entry direction** (see label on the Card). When the controller is switched-on, display 1 visualizes  and display 2 visualizes .¹

	Press	Display	Do
1	 	  visualizes  visualizes 	Select  if values stored on the Memory Card must be loaded on the controller. Selecting  the data of the controller will be kept unchanged.
3		The controller loads the value and the beep of internal buzzer confirms that data have been copied. Controller is ready	

Updating of Memory Card.

See also previous point., select  on display 2 to update the values of Memory Card ². Enter configuration mode and **change at least one parameter**. Quitting the configuration mode, the beep of internal buzzer will confirm that new values have been stored.

¹ If data stored on Memory Card are correct.

² In case that the controller does not visualize 

8. Configuration parameters

P-01	General configuration
	<i>Define the type of PID action, enable or desable starting setpoint and waiting, select the number of cycles.</i>
	1st Digit – Type of PID action
0	Single reverse action
1	Single direct action
2nd Digit – Enable starting setpoint of cycle	
0	Starting Setpoint enabled
1	Starting setpoint desabled
3rd Digit – Enable waiting before cycle start	
0	Waiting enabled
1	Waiting desabled
4th Digit – Select number of cycles available for the operator	
1..4	1..4 cycles available

P-02	Configuration of universal analogical input AN1
	<i>Select type of di sensor , visualization and measure unit</i>
	1st Digit – Thermocouple / Thermoresistence
0	Type K (-200/1370°C)
1	Type S (-120/1840°C)
2	Type R (-120/1840°C)
3	Type J (-200/1220°C)
4	PT100 (-210/870°C)
5	NI100 (-70/190°C)
6	Input 0...10V
7	Input 0...20mA
8	Input 4...20mA
2nd Digit – Decimal point	
0	No decimal point
1	Visualization with decimal point
3rd Digit – Select measure unit	
0	°C
1	°F

P-03	Reserved
P-04	Reserved
P-05	Configuration of control output
	<i>Select control output</i>
0	Control relay OUT1- Alarm 1 SSR - Alarm2 OUT2
1	Control SSR - Alarm 1 OUT1 – Alarm 2 OUT2
P-06	Lower limit of setpoint (-999/9999 digit)
P-07	Upper limit of setpoint (-999/9999 digit) <i>Set the limits of setpoint which may be entered by the operator</i>
P-08	Lower limit of scale (-999/9999 digit).
P-09	Upper limit of scale (-999/9999 digit). <i>Set the limits of the scale for the rating of values to visualize in case that inputs are configured as V or mA.</i>
P-10	Alarms hysteresis (-99.9/999.9 digit). <i>Hysteresis for the rating of alarms operation . Useful to avoid dangerous oscillations of outputs.</i>
P-11	Reserved

P-12	Configuration alarm no.1
P-13	Configuration alarm no.2
	<i>Alarms operation (see graphs of chap. 5). Acoustic / visual signal joined to cycle stop can be selected. Comparison values for graphs are defined by parameters P-15..16.</i>
	1st Digit –Type of operating
0	Not used
1	Absolute - related to process
2	Band
3	Upper deviation
4	Lower deviation
5	Absolute - related setpoint
6	Timed - related to step
	2nd Digit –Operation zone
0	“Under” by absolute or deviation alarm “inside” by band alarm
1	“Over” by absolute or deviation alarm. “Outside” by band alarm
	3rd Digit –Type of action on cycle
0	No action
1	Acoustic signal only
2	Cycle stop , 0% output , acoustic and visual ³ signal.
3	Cycle stop,100% output , acoustic and visual ³ signal

P-14	Reserved
P-15	Comparison value for alarm no.1 (-999/9999 digit).
P-16	Comparison value for alarm no.2 (-999/9999 digit).

³ Visual signal is **ALL. 1** or **ALL2** to indicate the active alarm;

It stays until the key  is pressed by the operator.

P-17	Configuration of digital input IN1
	Select the operating of digital input. Impulse means closed / open contact for at least 150msec
	1st Digit – Operating of input
0	Not used
1	Input START/STOP at impulse (≥ 150 msec)
2	RUN while active. The controller is ON and executes the cycle which is selected on the 3 rd digit of this parameter, until the contact is closed (or open)
3	Temporary stop of cycle ; writing  flashing
4	Input HOLD. Setpoint may be changed by keyboard
5	Input MASTER/SLAVE. If input is active the controller works as slave unit, if not it works as Master
2nd Digit – Type of contact	
0	Active with closed contact
1	Active with open contact
3rd Digit - Cycle or function to start	
0	Start the last cycle
1...4	Start cycle no.1...4

P-18	Reserved
P-19	Reserved
P-20	Reserved
P-21	Waiting for step end (1/1440 min. 0 disables the function) See 10.2 for details
P-22	Max. gap from step end (1/200 digit). <i>When the gap between setpoint-process1 is lower this value, the controller skips to the following step without waiting for the time programmed on P-21. For further detail, see 11.2.</i>

P-23	Recovery of interrupted cycle <i>Enable the recovery of an interrupted cycle in case of black-out. For further details see 10.1.</i>
0	Cycle recovery desabled
1	Cycle recovery enabled
P-24	Reserved
P-25	Reserved
P-26	Offset correction for input AN1 (-15.0/15.0 digits)
P-27	Gain calibration for input AN1 (-10.0%...+10.0%) <i>Add to the value measured by the sensor a certain number of units or a percentage value in order to correct the visualized value.</i>
P-28	Reserved
P-29	ON/OFF hysteresis or dead band (-99.9/999.9 digit). <i>Hysteresis for control output in ON/OFF mode. Useful to avoid dangerous oscillations when process is very close to setpoint value.</i>
P-30	Max. time for impulse (1/120 sec). <i>Cycle time for time-proportioning outputs. Example: if P-30 is set as 10 seconds, this means 60% output when the output is active for 6.0 seconds, not active for 4.0 seconds and so on.</i>
P-31	Reserved
P-32	Reserved
P-33	Reserved

P-34	Reserved
-------------	----------

P-35	Reserved
-------------	----------

P-36	Proportional band (0-9999 digit). (0 excludes P.I.D.)
-------------	--

P-37	Integral time (0/9999 sec). (0 excludes Integral)
-------------	--

P-38	Derivative time (0.0/999.9 sec). (0 excludes Derivative)
-------------	--

Set the parameters for P.I.D..

P-49	Configuration of serial input
-------------	-------------------------------

Select baud rate and enable ability answer delay for MODBUS according to baud rate

1st Digit – Baud rate

- 0** Baud rate 38400
- 1** Baud rate 19200
- 2** Baud rate 9600
- 3** Baud rate 4800

2nd Digit – Answer delay Modbus

- 0** Delay Modbus desabled
- 1** Delay Modbus enabled (3, 6, 9, 12 ms).


P-50	Slave address (1/99).
-------------	-----------------------

Modbus address for slave module

9. Alarms operating

Two alarms can be programmed and connected to outputs (OUT1, OUT2, SSR). The graphs below describe the programmable operations.

Band alarm (setpoint-process)




Band alarm active:

- outside
- inside

Example: outside

Deviation alarm (setpoint-process)




- Upper deviation

- Lower deviation

Example: upper deviation

Independent alarm (process)




- Active over

- Active under

Example : active over


Independent alarm (setpoint)



- Active over
 - Active under
- Example: active over

All operations can be joined to cycle stop and/or acoustic / visual signal .


Programmable operating (timed ⏳)



ON- or OFF-state of auxiliary output can be selected for each step of the cycle. State is selectable also at cycle end. See 5.1.

10. Software functions


10.1 Recovery of interrupted cycle



Cycle recovery is particularly useful for firing plants. After a black-out, the controller ATR420 can restart the cycle from the point at which it was interrupted. The gradient will be the same of the running step.

⚠ To disable the function, set parameter 23 to 0 (zero)

10.2 Waiting



⚠ To disable the function, set parameter 21 at 0 (zero).

When the function Waiting is working, the chronometer stops and display 2 visualizes



instead of step number.

The function is useful for firing cycles on industrial kilns in case that the plant is unable to reach the programmed temperature (setpoint) in the given time. If the gap between process value and setpoint is bigger than the value entered on parameter 22, the next step will start only after elapsing of the time programmed on parameter 21 or when the gap is lower than parameter 22 (see graph beside).

To quit the function manually, press

11. Protocol Modbus RTU

11.1 Main features

ATR420 is conceived for use and remote connection via MODBUS protocol. Serial RS485 enables the programming and the reading of sensor input.

Baud-rate	Selectable by parameter 38400 bits/sec 19200 bits/sec 9600 bits/sec 4800 bits/sec
Format	8, N, 1(8bit, no parity, 1 stop)
Supported functions	WORD READING (max 1 word) (0x03, 0x04) SINGLE WORD WRITING (0x06)

11.2 Addresses of words ATR420

MODBUS ADDRESS	DESCRIPTION	READ/WRITE	RESET VALUE ³
1	Process	R	0
2	Operating temperature	R	0
3	Setpoint	R	0
4	Percentage of output	R	0
5	Parameter 1 (P-01)	R/W	EEP
6	Parameter 2 (P-02)	R/W	EEP
7	Parameter 5 (P-05)	R/W	EEP
8	Parameter 6 (P-06)	R/W	EEP
9	Parameter 7 (P-07)	R/W	EEP
10	Parameter 8 (P-08)	R/W	EEP
11	Parameter 9 (P-09)	R/W	EEP
12	Parameter 10 (P-10)	R/W	EEP
13	Parameter 12 (P-12)	R/W	EEP
14	Parameter 13 (P-13)	R/W	EEP

³ According to initialization value at starting, the following possibilities are given:

1. "EEP" value stored on Eeprom.
2. "?" values unknown at starting

15	Parameter 15 (P-15)	R/W	EEP
16	Parameter 16 (P-16)	R/W	EEP
17	Parameter 17 (P-17)	R/W	EEP
18	Parameter 21 (P-21)	R/W	EEP
19	Parameter 22 (P-22)	R/W	EEP
20	Parameter 23 (P-23)	R/W	EEP
21	Parameter 26 (P-26)	R/W	EEP
22	Parameter 27 (P-27)	R/W	EEP
23	Parameter 29 (P-29)	R/W	EEP
24	Parameter 30 (P-30)	R/W	EEP
25	Parameter 36 (P-36)	R/W	EEP
26	Parameter 37 (P-37)	R/W	EEP
27	Parameter 38 (P-38)	R/W	EEP
28	Parameter 49 (P-49)	R/W	EEP
29	Parameter 50 (P-50)	R/W	EEP
50	Byte Display1 (4 th digit)	R	EEP
51	Byte Display1 (3 rd digit)	R	EEP
52	Byte Display1 (2 nd digit)	R	EEP
53	Byte Display1 (1 st digit)	R	EEP
54	Byte Display2 (4 th digit)	R	EEP
55	Byte Display2 (3 rd digit)	R	EEP
56	Byte Display2 (2 nd digit)	R	EEP
57	Byte Display2 (1 st digit)	R	EEP
58	Byte Led	R	EEP
59	Byte keys	W	EEP

12. Error messages

In case that the plant does not work properly, the controller stops the running cycle and shows a fault condition. See table below for description of fault messages.

#	Cause	Do
E-01	Programming error E ² PROM.	-
E-03	Wrong cycle data	Program a new cycle.
E-04	Wrong configuration data . Possible lost of configuration data	Check configuration parameters.
E-05	Disconnected or open sensor / temperature out of range	Check sensors connection
E-07	Wrong cycle data. Recovery function not available	Confirm and start a new cycle
E-11	Cold junction failure. Ambient temperature out of range	-

13. Technical data

13.1 Main features

Visualizers	8 displays (0,56 inches)
Operating conditions	0-45°C, humidity 35..95uR%
Sealing	IP54 Frontal
Material	ABS self-extinguish
Weight	450g
Sizes	48x96(frontal)x135mm

13.2 Hardware data

Analogical inputs	1: AN1, Configurable Input no.1 Thermocouple K, S, R, J Thermoresistances PT100, Ni100 Input V/I 0-10V, 0-20mA, 4-20mA	Accuracy (25°C) 0.2 % ± 1 digit for input TC, RTD, V/I
	2 relays: OUT1, OUT2	
Relay outputs	Configurable as control and alarm	Contacts capacity 8A-250V~
SSR output		1 linear output
		Configurable as control or alarm Output 12Vdc 30mA
Serial input	1: RS485 Serial input, MODBUS protocol	
Digital input	1: IN1 Configurable as input START, STOP, signal  , input HOLD	

13.3 Main software data	
Control action	ON-OFF with hysteresis P, PI, PID, PD time-proportioning
Proportional band	0...9999°C or °F
Integral time	0...9999 sec (0 excludes Integral)
Derivative time	0,0...999,9 sec (0 excludes Derivative)
Functions	Auto-Tuning , programmable alarms
Programmable cycles	4 cycles - max 15 segments (step) Operation as simple controller with programmable setpoint also available

Configuration table

Date:	Model ATR420:
Installer:	Plant:
Notes:	

P-01	General configuration	
P-02	Configuration analogical input AN1	
P-03	Reserved	
P-04	Reserved	
P-05	Configuration of control output	
P-06	Lower limit of setpoint(-999/9999 digit)	
P-07	Upper limit of setpoint (-999/9999 digit)	
P-08	Lower limit of scale (-999/9999 digit)	
P-09	Upper limit of scale (-999/9999 digit)	
P-10	Alarms hysteresis (-99.9/999.9)	
P-11	Reserved	
P-12	Configuration alarm no.1	
P-13	Configuration alarm no.2	
P-14	Reserved	
P-15	Comparison value for alarm no.1(-999/9999 digit)	
P-16	Comparison value for alarm no.2(-999/9999 digit)	
P-17	Configuration for digital input IN1	
P-18	Reserved	
P-19	Reserved	
P-20	Reserved	
P-21	Waiting for step end (1/1440 min)	
P-22	Max. gap for step end (1/200 digit)	
P-23	Cycle recovery	
P-24	Reserved	
P-25	Reserved	
P-26	Offset correction AN1 (-15.0/15.0 digit)	
P-27	Gain calibration AN1(-5.0%...+5.0%)	

P-28	Reserved	
P-29	ON/OFF hysteresis or Dead band (-99.9/999.9 digit)	
P-30	Max. time for impulse (1/120sec)	
P-31	Reserved	
P-32	Reserved	
P-33	Reserved	
P-34	Reserved	
P-35	Reserved	
P-36	Proportional band (0-9999 digit)	
P-37	Integral time (0/9999 sec).	
P-38	Derivative time (0.0/999.9 sec).	
P-49	Configuration of serial input	
P-50	Slave address (1/99).	

PIXSYS
Via Tagliamento, 18
30030 Mellaredo di Pianiga (VE)
www.pixsys.net
e-mail: sales@pixsys.net - support@pixsys.net

Software Rev.2.20

2300.10.062-RevA 130505

2300.10.062-A